



## Roller Selection Guide

50mm Tube												
	Width											
DROP	600	900	1200	1500	1800	2100	2400	2700	3000	3300	3800	4100
500	√	√	√	√	√	√	√	√				
1000	√	√	√	√	√	√	√					
1500	√	√	√	√	√	√						
2000	√	√	√	√	√	√						
2500	-	√	√	√								
3000	-	√	√	√								

60mm Tube												
	Width											
DROP	600	900	1200	1500	1800	2100	2400	2700	3000	3300	3800	4100
500	√	√	√	√	√	√	√	√	√	√	√	
1000	√	√	√	√	√	√	√	√	√	√	√	
1500	√	√	√	√	√	√	√	√	√	√		
2000	√	√	√	√	√	√	√	√	√	√		
2500	√	√	√	√	√	√	√	√	√	√		
3000	-	√	√	√	√	√	√	√	√			
3500	-	√	√	√	√	√	√					
4000	-	-	√	√	√	√						
4500	-	-	√									

80mm Tube												
	Width											
DROP	1200	1500	1800	2100	2400	2700	3000	3300	3800	4100	4400	4700
1000	√	√	√	√	√	√	√	√	√	√	√	√
1500	√	√	√	√	√	√	√	√	√	√	√	√
2000	√	√	√	√	√	√	√	√	√	√		
2500	√	√	√	√	√	√	√	√	√	√		
3000	√	√	√	√	√	√	√	√	√			
3500	-	√	√	√	√	√	√	√				
4000	-	√	√	√	√	√	√					
4500	-	√	√	√	√	√	√					
5000	-	-	√	√	√	√						
5500	-	-	√	√	√							
6000	-	-	-	√	√							
6500	-	-	-	-	√							
7000	-	-	-	-	√							

- NOT ADVISED – Fabric Stability ('Roll Off')

NOT ADVISED – Roller Bowing

Note the above tables are a guide ONLY for the 20Nm motor.  
Roller selection must take account of fabric weight and weave stability.